Stbeat

Quick Start Guide

Instructions for:

- 1. Getting Started
- 2. Downloading the Orangetheory App
- 3. Charging Device
- 4. Proper Placement
- 5. Pairing Device
- 6. LED Guide
- 7. Caring for Device
- 8. Technical Specifications

Getting Started:

- 1. Included in packaging: OTbeat Burn, SM band, MD band, & USB cord
- 2. Remove OTbeat Burn from packaging
- Connect USB cord into charging port of device to wake the device from manufacturing sleep mode
- 4. LED light will appear after a few seconds


Downloading the Orangetheory App:



Note: Fully charge device before attempting to pair for the first time.

Charging Device:

- 1. Open rubber port cover on back of device
- 2. Plug in mini-USB connector into device port
- 3. Plug in regular USB connector into charging block (not provided)
- 4. Plug in charging block into wall outlet



Device can be connected directly to a computer USB port for charging. Note: Charging time will vary due to differences in voltage between wall outlet and computer.

Battery is fully charged when Green LED is continuously on During charging: Red LED light will blink slowly LED indication for charging is on front of device

Proper Placement:

To transmit accurate data from your device:

- 1. Fasten device snugly around the bicep with the module pointing away from the body.
- 2. The optical sensor should make good contact with skin



Page 4

Pairing Device:


1. Once OTbeat Burn is fully charged, double click the center of the Splat to power ON the device



Pairing Device (Cont.):

- 2. Launch the settings app on your mobile device
- 3. Ensure your bluetooth settings are on





Page 6

Pairing Device (Cont):

4. Open Orangetheory app on mobile phone.



OTbeat Burn - Pairing Device

Pairing Device (Cont.):

5. In Orangetheory app, go to settings to ADD DEVICE.

*Once device appears, OTbeat Burn is successfully connected to app



LED Guide

Heart Rate Detection LED Indication:

Alternating BLUE and GREEN: Detecting heart rate Alternating BLUE and RED: No heart rate detected Blinking GREEN: Heart rate detected Blinking ORANGE: Heart rate zones are changing

Bluetooth Connection State:

Blue LED blinks for 5 seconds: After turning on the unit Blue LED continuously on for 5 seconds: Connected Green LED continuously on: Updating firmware

Battery LED Light

During Charging: Red LED blinks slowly: Charging Green LED continuously on: Battery full

Battery State:

Red LED blinks three times: Low battery at <15% (repeat every 5 min. until reach critical level) Red LED continuously on for 2 sec: Device powering off

Caring for Device:

- 1. To ensure accurate readings, clean the sensors with a soft cloth after use
- OTbeat Burn unit and strap are waterproof to IP67 specifications and can be easily cleaned with mild soap and cool water
- Use a cotton swab and rubbing alcohol to clean the USB charging contacts when necessary. Do NOT contact USB charging port
- 4. Do not use any abrasive chemicals to clean the OTbeat Burn unit, sensor, or strap. This will cause permanent damage

Technical Specificat	ions:
Feature	Description
Functions	heart rate detection and transmission (Bluetooth 5.1), battery low alert
Heart Rate Range	30 to 220 BPM in 1 BPM resolution
Heart Rate Accuracy	+/-5 BPM
Transmission	BLE
Power Supply	3.8V Li-ion Polymer rechargeable battery
BLE Transmission Distance	15 Meters
Battery Life time (PPG&BLE_always on)	Up to 24 hours of continuous detection
Water Resistance Level	IP67
Storage Temperature	-20 to +60°C
Operating Temperature	0 to +40°C
Memory capacity	6 hours detection

Page 11

For more information visit orangetheory.com



A								-
								-
\square								
No.	交更者	变	更日期	支更记录				
	🗶 FSD # 844							
1	80 番信料	×	科号			成型尺寸(mm)	长x宽i	x高 展开尺寸: 172*86mm, 成型尺寸: 86*86mm
- AR		OT	취영	项目型号	FD200	成型尺寸(mm) 材质	textto	3篇 展升尺寸: 172*86mm, 成型尺寸: 86*86mm 80g哑粉纸
-	5			项目型号 客户型号	FD200 OTbeat		长x宽x	
8	e 8 202	OT	-12			材质	长cc	80g哑粉纸
品! 日詳	e 1 202 F	OT 3-12	-12	客户型号	OTbeat	材质 颜色 表面处理		80g吨粉纸 单照印刷